

Safety Trailer Generator setup/breakdown and Power On/Off Last Updated: 07/05/2019

GENERATOR SETUP

- 1 - Get ramps out and secure to control cabinet floor. Make sure pins in holes
- 2 - Unstrap generator
- 3 - Turn ON winch controller after removing from velcro
- 4 - Push OUT button and guide generator down ramp
- 5 - Detach winch cable
- 6 - Position generator as far away from trailer as possible
- 7 - Turn OFF winch controller and return to velcro holder

POWER ON

- 1 - Start Generator
- 2 - Plug extension cord in
- 3 - Push ON/TEST Button on UPS

**Hold about 3 seconds

{Uninterruptible Power Supply}

**Everything should power up



POWER OFF

- 1 - Turn off all TV's, lights, heated door vents, etc
 - 2 - Push and hold STOVE OFF button until says "SHUTTING DOWN"
- **The above MUST be done first!
- 3 - Turn OFF ALL breakers on the generator
 - 4 - Turn OFF the Generator
 - 5 - Push OFF on UPS twice and hold second time until beeps
 - 6 - Unplug extension cord

GENERATOR BREAKDOWN

- 1 - Position generator at foot of ramps
 - 2 - Attach winch cable
 - 3 - Turn ON winch controller after removing from velcro
 - 4 - Push IN button and guide generator up ramp
- **Do NOT winch all the way in!! Wheels MUST touch stops!
- 5 - Turn OFF winch controller and return to velcro holder
 - 6 - Strap generator

7 - Remove ramps and secure in "BEDROOM"

**Ramps, Extinguishes, Prop Box secured



**Generator secured (Note: Strap around generator frame and extension cord on side opposite exhaust!)

